

Market-Inspired Formulation

Polyaldo® HGDS KFG (6-2-S) + Polyaldo® 10-1-S Pastillated Emulsion Base

Formulation # CB-1

Ingredient	INCI Nomenclature	Supplier	%
Phase A			
Polyaldo® 10-1-S Pastillated	Polyglyceryl-10 Stearate	Lonza Consumer Care	1.33
Polyaldo® HGDS KFG (6-2-S)	Polyglyceryl-6 Distearate	Lonza Consumer Care	0.67
ESP Shea Oil	<i>Butyrospermum Parkii</i> (Shea) Oil	Earth Supplied Products, LLC	7.50
Jeechem™ CTG	Caprylic/Capric Triglyceride	Jeen International	7.50
Cyclogol™ CS5050	Cetyl Stearyl	Cedar Concepts	3.00
Phase B			
–	Water	–	q.s.
–	Glycerin	–	3.00
Keltrol™ CG-SFT	Xanthan Gum	CP Kelco	0.25
Phase C			
Mikrokill® C0S	Phenoxyethanol (and) Chlorphenesin (and) Caprylyl Glycol	Lonza Consumer Care	0.75

www.lonza.com

www.lonza.com/personalcare

Specifications

pH: 4.00–6.00
Viscosity: 22,000–28,000cps
[Spindle T-D, 4 RPM at 25°C, measured after 24 hours]
38,000–46,000cps
[Spindle T-D, 4 RPM at 25°C, measured after two weeks]

Procedure

1. Combine phase A to main vessel. Begin heating the batch to 75°C. Mix until uniform.
2. In a separate vessel, add water and heat to 70–75°C; add the hot water into premixed glycerin and xanthan gum mixture with mixing. Mix until uniform to get phase B.
3. Add phase B to phase A. Mix until uniform. Then begin cooling.
4. When main vessel reaches below 30°C, add preservatives phase C to main vessel.
5. Mix for another 15 minutes. Let rest until room temperature.

Lot # GL NB-2892-50-1

USA

Lonza Consumer Care
70 Tyler Place
South Plainfield, NJ 07080
Tel +1 908 561 5200

Switzerland

Lonza Ltd
Muenchensteinerstrasse 38
4002 Basel
Tel +41 61 316 81 11

Review and follow all product safety instructions. All product information corresponds to Lonza's knowledge on the subject at the date of publication, but Lonza makes no warranty as to its accuracy or completeness and Lonza assumes no obligation to update it. Product information is intended for use by recipients experienced and knowledgeable in the field, who are capable of and responsible for independently determining the suitability of ingredients for intended uses and to ensure their compliance with applicable law. Proper use of this information is the sole responsibility of the recipient. This information relates solely to the product as an ingredient. It may not be applicable, complete or suitable for the recipient's finished product or application; therefore republication of such information or related statements is prohibited. Change to "No claims are made herein for any specific intermediate or end-use application. Information provided by Lonza is not intended and should not be construed as a license to operate under or a recommendation to infringe any patent or other intellectual property right. All trademarks belong to Lonza or its affiliates or to their respective third party owners and are used here only for informational purposes.

All trademarks belong to Lonza or its affiliates, or to their respective third party owners.

© 2015 Lonza
